




DIGITAL MIXING SYSTEM


RIVAGE
PM

Block Diagram



Block Diagram

System Overview (PM10, PM5, PM3)








(*2) Supported cards: TWINLANE network cards and other HY cards




(*2) Supported cards: TWINLANe network cards and other HY cards







(*1) The number of channels varies depending on the model. Refer to the following information.
CSD-R7: INPUT 1-144, MIX 1-60, MATRIX 1-36
DSP-R10: INPUT 1-144, MIX 1-72, MATRIX 1-36
DSP-RX-EX: INPUT 1-288, MIX 1-72, MATRIX 1-36
DSP-RX: INPUT 1-120, MIX 1-48, MATRIX 1-24






(*1) The number of channels varies depending on the model. Refer to the following information.
 CSD-R7: INPUT 1-144, MIX 1-60, MATRIX 1-36
 DSP-R10: INPUT 1-144, MIX 1-72, MATRIX 1-36
 DSP-RX-EX: INPUT 1-288, MIX 1-72, MATRIX 1-36
 DSP-RX: INPUT 1-120, MIX 1-48, MATRIX 1-24




(*1) The number of channels varies depending on the model. Refer to the following information.
 CSD-R7: INPUT 1-144, MIX 1-60, MATRIX 1-36
 DSP-R10: INPUT 1-144, MIX 1-72, MATRIX 1-36
 DSP-RX-EX: INPUT 1-288, MIX 1-72, MATRIX 1-36
 DSP-RX: INPUT 1-120, MIX 1-48, MATRIX 1-24



(*1) The number of channels varies depending on the model.
Refer to the following information.
CSD-R7: INPUT 1-144, MIX 1-60, MATRIX 1-36
DSP-R10: INPUT 1-144, MIX 1-72, MATRIX 1-36
DSP-RX-EX: INPUT 1-288, MIX 1-72, MATRIX 1-36
DSP-RX: INPUT 1-120, MIX 1-48, MATRIX 1-24



Level Diagram



Yamaha Pro Audio global website
<https://www.yamahaproaudio.com/>
Yamaha Downloads
<https://download.yamaha.com/>